



## PMD-661 MKIII

Latest Firmware Version: 1.38

Release Date: July 27<sup>th</sup>, 2017

### Firmware Update Instructions

1. Using a computer, add the **PMD661update.bin** file to the root of the SD card.
2. Remove the SD card from the computer and insert it into the PMD-661 MKIII.
3. Power on the PMD-661 MKIII. You will be prompted to update the firmware. Follow the prompts. Once complete, the unit will power off.
4. Power the PMD-661 MKIII **On**. Choose **MENU > 6 F/W Version** and press **ENTER**. Confirm the firmware has been updated.

### Changes in V1.38

- Power button is now locked when **KEYLOCK** is engaged so the user cannot power the unit off with **KEYLOCK** on.
- Other minor bug fixes.

### Technical Support

For additional help, visit [www.marantzpro.com/support](http://www.marantzpro.com/support)